Samsung Memoir™

PRODUCT SPECIFICATIONS

FEATURES
- Advanced Responsive Touch Screen
- Quick Access Customizable Widgets
- Real Web Browsing (web2go℠)
- Supports POP3 Emails
- Full QWERTY Touchpad
- 8.0 Megapixel Digital Camera
- Multiple Messaging Options (Text Messaging, Picture Messaging, Video Messaging, Email, IM)
- Bluetooth® Wireless Technology**
- Organizer: Alarm, Calculator, Calendar, Converter, Memo, Task List, Timer, Stop Watch, RSS Reader
- Advanced Speech Recognition
- Voice Memo
- 72-Note Polyphonic Ringtones
- Volume Up/Down Keys
- Vibrate Mode
- Phonebook holds up to 1,000 entries
- TTY (M3) capable
- Graphic Format Support (BMP, PNG, BCI, JPEG, GIF, PMD)
- Audio Format Support (MP3, AAC/ AAC+, MPEG4, WAV, MIDI)
- Video Format Support (MPEG4, H.263, H.264, 3GPP)
- MegaTones and HiFi Ringers
- myFaves® Capable
- EDGE high-speed data
- GPRS
- USB Interface
- Games
- Music Player (MP3)
- Wallpaper

TECHNICAL SPECIFICATIONS
- GSM 850, 900, 1800, 1900; UMTS Band IV, Band I
- Dimensions: 4.17” x 2.11” x 0.55” (standard battery)
- Weight: 4.4 ounces (standard battery)
- Display: 240 x 400 Pixels, 262K TFT
  - Touch-Sensitive 1.61” x 2.64” LCD Display
- Operating System: Proprietary
- Talk Time: Up to 5.5 hours (standard battery)
- Standby Time: Up to 300 hours (standard battery)
- Hearing Aid Compatibility = M3

MEMORY
- Internal Memory: 100MB
- External Memory: Up to 16GB microSD™ Card

INTEGRATED 8.0 MEGAPIXEL DIGITAL CAMERA
- 8.0 Megapixel CMOS Auto Focus Camera and Camcorder
- 16x Digital Zoom
- Multi Shot
- Xenon Flash
- Shooting Mode: Single, Continuous, Panorama, Smile Shot, Mosaic
- Recording Mode: Normal, Picture Message, Slow Motion
- Self-Timer (2, 5 or 10 seconds)
- Video and MMS Clips: Up to 1 hour of video, up to 30 seconds of MMS
- Scene Support: Portrait Mode, Landscape Mode, Night Shot, Sports, Indoor, Beach/Snow, Sunset Mode, Dawn, Fall Color, Fireworks, Backlight
- Upload images to Flickr®, Kodak Gallery, Snapfish™, Photobucket

CALL MANAGEMENT AND SERVICES
- Voice Dialing
- Caller ID*
- Voicemail*
- Call Forwarding*
- Call Waiting*
- Three-Way Calling*
- Call History
  - All Calls
  - Last 90 Incoming, Outgoing, and Missed Call Logs
- Speakerphone
- Speed Dial
- Automatic Redial
- Phonebook
  - Photo Caller ID (one picture with each entry)
  - One-, Two-, and Three-Touch Dialing

ACCESSORIES
- Standard Battery
- Car Power Charger
- Travel Charger
- Hands-free/Stereo Headset
- Mini Cube Speaker
- S20 Pin to 3.5mm Adapter Cable
- Bluetooth® Car Kits
- Mono/Stereo Bluetooth® Headset
- USB Data Cable
- Leather Case
- 5-in-1 Mobile Reader (microSD™/ TransFlash®)
- 1GB microSD™/TransFlash® Card with adapter
- TV-Out S20 Pin to Video/Audio Cable

STANDARD PACKAGE CONTENTS
- Samsung Memoir Phone
- Standard Battery
- Travel Adapter
- Data Cable
- 1GB microSD™ Card plus adapter
- Hands-free Headset
- English and Spanish User Guide
- Start Guide
- Services Guide
- Terms & Conditions

“number one in brand loyalty seven years in a row”

Samsung mobile phones have been rated number one in brand loyalty by consumers seven years in a row, according to Brand Keys, a leading independent authority on brand loyalty.

*Many of the services and features described above are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas. Other conditions and restrictions apply. See carrier for more information. All talk and standby times are approximate. Battery performance depends on network configuration, signal strength, operating temperature, features selected, and voice, data, and other application usage patterns. Internet content/services designed for mobile devices.

**The Samsung Memoir™ (SGH-t929) supports Bluetooth Profiles for wireless handsets, hands-free accessories, and object exchange. Both devices must be compatible with object exchange profile. Copyrighted material cannot be transferred.

© 2009 Samsung Telecommunications America, LLC (“Samsung”). Samsung is a registered trademark and Memoir™ is a trademark of Samsung Electronics America, Inc. and its related entities. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated.

01/2009

Samsung Memoir™

SGH-t929

INFORMATION GUIDE

8.0 MEGAPIXEL DIGITAL CAMERA
Capture and share professional quality photographs and videos with the Memoir’s 8.0 megapixel digital camera with auto focus, smile shot and built-in Xenon flash. The TV-Out feature lets you connect to your TV and view slide shows of your photos.

TOUCH SCREEN WITH CUSTOMIZABLE WIDGETS
The Memoir has an advanced responsive touch screen that reacts in a tactile way to your touch. Customize your widgets to access the applications that you use the most, like checking the weather and uploading pictures to Snapfish™.

ADVANCED GPS NAVIGATION
Search for local businesses or enter a specific address using TeleNav®. It gives audible turn-by-turn directions to your destination. Geotagging lets you include exact mapping coordinates in your pictures.

EXPANDABLE MEMORY
With the Memoir’s expandable memory, you can store all of your pictures, videos and music. Memory expands up to 16GB. 1GB card included.

SAMSUNG TELECOMMUNICATIONS AMERICA
1301 E. Lookout Drive | Richardson, TX 75082 | 1.800.SAMSUNG

https://training.samsungtelecom.com
www.samsungmobileusa.com

password: myfaves

Samsung Memoir™

MENU NAVIGATION

1. AUDIO POSTCARD

2. CALL LOG
1: All Calls
2: Missed Calls
3: Outgoing Calls
4: Incoming Calls
5: Call Time
6: Delete

3. WEB
1: Home
2: Enter URL
3: Bookmarks
4: Browser Settings

4. MUSIC PLAYER
1: All Tracks
2: <individual track selected>
3: Playlists
4: Artists
5: Albums

5. MESSAGING
1: Create Message
2: Inbox
3: Email
4: IM
5: Outbox
6: Drafts
7: My Folders
8: Templates
9: Messages Settings
10: Delete by Folder
11: Memory Status

6. APPLICATIONS
1: Files
2: Games and Applications
3: Alarm
4: Voice Recognition
5: Tasks
6: Memo
7: Calculator
8: World Clock
9: Converter
10: Timer
11: Stop Watch
12: RSS Reader

7. CAMERA

8. PHOTOS
1: My Album
2: Take Photo
3: Create Folder
4: Manage
5: Delete
6: More
7: With a Photo Selected

9. VIDEOS
1: Record Video
2: Create Folder
3: Manage
4: Delete
5: More

10. HELP

11. CALENDAR
1: Create Event
2: Go To
3: Event List
4: More

12. SETTINGS
1: Widget
2: myFaves Settings
3: Sound Profiles
4: Display Settings
5: Manage Cameo Frame
6: Time and Date
7: Phone Settings
8: Bluetooth
9: Call Settings
10: Application Settings
11: Network Selection
12: Memory Settings
13: Reset Settings
14: Software Update (SIM dependent feature — Displays when a memory card is inserted)
15: Camera (Displays only if supported by your SIM card)

Get to know the Samsung Memoir™

BLUETOOTH® SETUP
Your phone comes with Bluetooth® Wireless Technology, which enables a data connection between your phone and a Bluetooth® wireless headset.

Pair a Bluetooth® Wireless Headset
To pair your phone with a Bluetooth® headset, make sure that your headset is fully charged and that you put the headset into pairing mode. See your Bluetooth® headset's manual for more information.

Turn on the Bluetooth® Feature and Pair with a Headset
1. Touch **Menu** > **Settings** > **Bluetooth**.
2. Touch **Turn On**. Your phone scans for available Bluetooth® devices.
3. Touch the headset to select it.
4. Type the PIN if needed.
5. Touch **OK**.

CUSTOMIZING YOUR WIDGETS ON YOUR WIDGET BAR
The Samsung Memoir has a Widget Bar with widgets that give quick access to the items you use most often. Drag the widget to move it to the home screen and tap to open. Although there are 21 widgets available, the bar only holds 14; 6 of which are visible on the screen at a time.
1. Touch **Menu** > **Settings** > **Widget**.
2. Select the widgets you want on your Widget Bar.
3. Touch **Save**.

SETTING UP YOUR WEATHER WIDGET
1. Touch the **Weather Widget** on your Widget Bar.
2. Touch the **Weather Widget** to enter your zip code. Enter your 5-digit zip code.
3. Touch **Done**.
4. Your local weather will appear.
5. Turn this into a 3-day forecast by touching the **Down Arrow** on the Weather Widget.

SEND AUDIO POSTCARD
1. Touch the **myFaves widget** on your Widget Bar.
2. Touch the myFaves contact you wish to send the Audio Postcard to.
3. Touch **Audio Postcard**.
4. Touch the **Left** or **Right Arrows** to navigate to the desired frame.
5. Frame the subject.
6. Press the **Camera Key** to take the picture.
7. Touch **Record Voice**, if desired, to record a voice message. Record your audio and touch the **Stop Icon** when you are finished speaking.
8. Touch **Send**.

USE CAMERA/CAMCORDER & PICTURE MESSAGING
Send Picture Messages
1. Touch **Menu** > **Messaging** > **Create Message**.
2. Tap the screen to display the keypad (or tilt the phone to display the QWERTY keyboard) and compose a message.
3. Touch **Done** when complete.
4. Touch **Image** > **Take photo**. This launches the camera. Take the photo to be used in the message.
5. Touch **Add**.
6. Touch **Send**. A list of options appears: Recent Recipients, Phonebook, New Number, New Email. Choose the Recipient.
7. The number or address appears in the To field.
8. Touch **Send**.

Separate charges may apply to send/receive domestic/international picture messages.

Use Smile Shot Feature on Camera
Smile Shot, one of the newest features on standalone cameras, ensures that the Samsung Memoir focuses on the subject, as opposed to the background scenery.
1. Press the **Camera Key** to open the camera.
2. Touch **Mode** > **Smile Shot**.
3. Frame the subject.
4. Press the **Camera Key** again to take the picture.

Upload Your Pictures to Flickr.com
1. Press the **Camera Key** to open the camera.
2. Touch **Default Destination** > **Change** > **Online Album**.
5. Touch **Flickr** (or Kodak Gallery, Photobucket or Snapfish) and input your Flickr ID.
6. Touch **Done** > **Save** > **Add**.
7. All of your pictures will now be uploaded to your Flickr account.

View Pictures on Television
Connect your phone to the TV with the TV-Out feature and watch a slide show of photos on the TV.
1. Connect TV-Out cable to both the TV and the device.
2. Configure your TV so that the Samsung Memoir device is the source.
3. Touch **Menu** > **Photos** > **Slide Show**.
4. Choose the music settings.
5. Touch the **Play Icon**.
6. Your pictures will be viewable on your device as well as the television when you are in slide show mode.

TV-Out cable does not come with device. Must purchase TV-Out cable accessory separately.